

JOBE E-DUNA SUP OWNERS MANUAL

(UK)

THIS MANUAL MUST BE READ BEFORE USING THIS PRODUCT

SAVE THIS OWNER'S MANUAL! KEEP FOR FUTURE REFERENCE

(FR)

CE MANUEL DOIT ETRE LU AVANT D'UTILISER CE PRODUIT

GARDER LE EN REFERENCE

(ES)

ESTE MANUAL DEBE LEERSE ANTES DE USAR EL PRODUCTO

GUARDAR ESTE MANUAL! TENERLO PARA FUTURAS CONSULTAS.

(NL)

LEES DEZE HANDLEIDING ZORGVULDIG VOORDAT U HET PRODUCT IN GEBRUIK NEEMT

BEWAAR DEZE HANDLEIDING VOOR TOEKOMSTIG GEBRUIK

(PT)

LEIA ESTE MANUAL ANTES DE USAR ESTE PRODUTO

GUARDE ESTE MANUAL DE UTILIZADOR PARA REFERENCIA FUTURA

(DE)

**DIESE BEDIENUNGSANLEITUNG MUSS VOR DER VERWENDUNG DIESES PRODUKTS
DURCHGELESEN WERDEN**

HEBEN SIE DIESE BEDIENUNGSANLEITUNG FÜR ZUKÜNFTIGE FRAGEN AUF

MANUFACTURED BY:

Jobe Sports International
Heerewaardensestraat 30,
6624 KK Heerewaarden
The Netherlands

tel. +31 (0) 487 573090
e-mail: info@jobesports.com
url: www.jobesports.com

JOBE 

Table of contents

Safety warning

A word of caution

Unpacking & Assembly

Drive

Batteries & Charging

Preparation & Inflation

Step by Step preparation guide

Compressor

Fin assembly

Paddle & Remote control

Drive operation

Packing up

Battery charge indicators


Troubleshooting

Repair kit & Repairs

Warranty & Liability

Serial number & Registration

Congratulations on being the proud owner of the new Jobe E-duna SUP Board and welcome to our family. First, a word of appreciation: clearly you have great taste in design and functionality and are an avid watersports fan, so we would like to thank you for purchasing a Board. This manual has all the information you'll need to keep your Board in good working condition, to paddle safely, and to manage all the features that sets the Board apart from other SUPs, namely self-inflation, operating the electric controls, and properly charging and storing the batteries.



▲ SAFETY WARNINGS and PRECAUTIONS ▲

Please read this Owner's Instruction Manual in its entirety before using this product and pay special attention to items that include any of the following terms: CAUTION, WARNING, DANGER, IMPORTANT, NOTICE, ONLY, MUST, ALWAYS, DO NOT, and NEVER.

SAFETY WARNING

PADDLEBoardING CAN BE VERY DANGEROUS AND REQUIRES INTENSE PHYSICAL EFFORT. THE USER OF THIS PRODUCT MUST BE AWARE THAT PADDLEBoardING ACTIVITIES MAY RESULT IN SERIOUS INJURY OR DEATH. CAREFULLY FOLLOW THESE SAFETY STANDARDS WHENEVER USING THIS PRODUCT.

- ALWAYS wear a nationally approved personal floatation device (PFD).
- ALWAYS wear the ankle leash provided.
- ALWAYS wear a helmet when appropriate.
- Dress appropriately for weather conditions; exposure to cold weather and cold water can result in hypothermia.
- Check all your equipment for signs of wear, tear, damage or malfunction before each use.
- Be aware of the natural elements that could impact your activity, such as weather condition and possible weather changes, water levels, tides, currents and wind.
- DO NOT use this product on open or white waters. Use it only on calm water.
- Use this product ONLY in areas that are considered appropriate for paddleboarding activities; make yourself familiar with the area before starting your activity.
- DO NOT use this product in flood conditions.
- NEVER paddle alone.
- DO NOT exceed your own abilities and experience level. Inexperienced paddleboarders should obtain appropriate paddleboarding training before using this product.
- Consult a physician regarding your physical fitness for the activity you intend to undertake.
- DO NOT tow from any other vehicle or boat. DO NOT tow any other vehicle, boat, or device.
- DO NOT use this product under the influence of alcohol or drugs.
- DO NOT allow children to operate the product without adult supervision.
- ALWAYS comply with all local water safety rules and applicable laws and regulations.

IT IS NECESSARY to read this manual and understand its content before you head out for your first paddling session with a board, as inside you will find all you need to know about safety, performance, maintenance, and service. Continue to refer to this manual as you enjoy your board.

⚠ WARNING By using this product you agree to accept the risks involved with paddleboarding activity and agree to follow all instructions, cautions, and warnings carefully at all times while using Jobe Sports' products.

⚠ WARNING It is the owner's responsibility to read and understand the this Instruction Manual and to instruct all other users in the safe operation of this product. By using this product you hereby agree to the Release of Liability and Claim Waiver Agreement in this manual. If anything is unclear or if you have any further questions, DO NOT hesitate to contact us at customerservice@jobesports.com. Your safety and enjoyment are our first concern. Wishing you calm waters.

A WORD OF CAUTION

Any athletic activity comes with a certain amount of personal risk, including but not limited to damage to person and property and in the most unfortunate incidents even death. Paddleboarding is no exception, with risks including, but not limited to, collisions with other paddlers, swimmers, marine wildlife, and natural or man-made objects. Fatigue and fast-changing weather conditions **MUST** also be taken into consideration. Appropriate safety equipment - including a life jacket and an ankle leash - thorough knowledge of water safety, responsible paddleboarding, and proper use and maintenance of your board can go a long way towards mitigating these risks.

The boards are not intended for dirty, polluted waters, nor ones with excessive vegetation, including algae, water lilies, grasses, branches, etc. Verifying the suitability of the water is your responsibility, and disregard of such circumstances that may impair the normal use of the product will **void the product's warranty**.

Before using any board it is your responsibility to determine what the maritime laws are in the area where you are paddling. Every country has its own rules and laws and it is up to you to determine what those are and to respect them.

Any sport on the water depends on natural factors. Always check the weather report before heading out, as well as tides, currents, and the presence of hard or sharp objects under the water's surface or on the shore, where you start your journey and come back from the water. Safety equipment - an ankle leash and a lifejacket - **MUST** be worn at all times when you are on a SUP. In many countries/waters this is actually required by law (and trends predict the spreading of this legal requirement).

⚠ WARNING DO NOT exceed the Maximum Weight Capacity of the board (Max. Weight). The recommended capacity of this product is 200lbs/90kg, while maximum capacity is 250lbs/115kg. Exceeding this weight may damage the product and make it dangerous for your safety.

Anyone under 18 should **ONLY** use a board with a parent's permission and the supervision of an adult.

⚠ WARNING The ability to swim is a **NECESSARY** skill for anyone who intends to use a SUP as you may risk drowning. If you cannot swim comfortably **YOU MUST NOT** use a board. **NEVER** use a board under the influence of alcohol or other substances.

⚠ WARNING Please note that the battery charge level indicator is **ONLY** intended to provide the user with a general understanding of remaining battery charge available. Users **MUST ONLY** use the board to cover distances that the user is comfortable reaching, and returning from, under physical paddle power **ONLY**, in the event of battery depletion or other failure of the system.


If you **DO NOT** agree with these provisions or are unwilling to take responsibility for verifying weather conditions and using appropriate safety equipment, or if you **DO NOT** know how to swim, then **DO NOT** use this product.

As the range of factors and the number of possible circumstances that could occur on the water is impossible to anticipate, by purchasing and/or using a board you are assuming such risks and indemnifying Jobe Sports International of any liability for damage to person or property to the greatest extent permitted by law.

UNPACKING AND ASSEMBLY

Open the board packaging carefully (DO NOT use sharp objects so as not to puncture the SUP) and ensure all the components are included. Immediately upon opening the box your board comes in, verify that it includes all the parts/components:

- | | |
|-------------------------------------|---|
| ① Board inflatable SUP | ⑦ Inflation hose |
| ② Drive, motor and compressor unit* | ⑧ Charger and cable** |
| ③ Collapsible paddle | ⑨ Dual-purpose safety and transport leash |
| ④ Fin | ⑩ Repair and service kit |
| ⑤ Remote control ring | ⑪ Board bag |
| ⑥ Battery pack | |



*If you ordered them along with your board, the bottom of the Drive will be outfitted with LEDs.

**The charger comes packed along with your Board, but DO NOT take it with you when you go out on the water. Leave it at home, in your car, or on your boat.

DRIVE


The Drive is what sets the board apart from any competitor. It is an integrated combination of compressor with inflation hose and motor with propeller. This is located in a plastic housing with an affixing cover and a protective mesh on the bottom.

The Drive may ONLY be opened when both the Drive and board are dry and resting on a soft, flat surface. IF WATER GETS INTO THE INSIDE OF THE Drive, YOUR WARRANTY IS VOIDED.


⚠ WARNING Opening the Drive's cover while the board is on the water is strictly prohibited, as it can be dangerous to your safety, and immediately voids your warranty.

⚠ WARNING Using the Drive without the protective mesh cover on the bottom is strictly prohibited. Using the Drive without the protective mesh being properly installed can cause injury to you and damage to the product. Not following this instruction and warning will immediately void the warranty.


SipaDrive top view




SipaDrive cover



SipaDrive side view



SipaDrive bottom view




protective mesh


optional LED light s



DO NOT OPEN IF WET!



DO NOT OPEN WHILE ON WATER!



DO NOT REMOVE PROTECTIVE MESH

!

BATTERIES

The battery will arrive with half a charge, so before use it MUST be charged using the included charger according to the directions included. SEE: CHARGING BATTERY. The battery can be transported in the Drive housing, as long as the battery is not connected to the Drive.

⚠ WARNING During transport and storage the battery MUST NEVER be exposed to temperatures above 120 °F (50 °C), as this will reduce the battery's lifespan and it may damage it permanently. DO NOT LEAVE the BATTERY IN YOUR VEHICLE ON A SUNNY DAY!

⚠ WARNING DO NOT transport the chargers together with wet components.


CHARGING THE [Drive] BATTERY

You will need to charge 2 batteries to start using the board: 1) the battery in the remote control ring, and 2) the battery for the Drive.

- 1) Use the charging cable to charge the battery in the remote control
- 2) With the same charger, charge the battery for the Drive

NOTE: The XX volt charger is suitable for power outlet voltage ranges of 110 VAC to 240 VAC (therefore universal, and compensates for differences in voltage automatically).

⚠ WARNING You MUST be physically present while the battery is charging . DO NOT leave a charging battery unattended. Disconnect power immediately if battery overheats or other signs of failure occur, including if the battery emits an unusual smell, feels hot, changes color or shape, or appears abnormal in any other way.



Charge the battery with the included charger in a completely dry environment. Make sure the battery is completely dry when charging. Attach the battery to the charger, and plug it into an electrical outlet/socket. The order you connect them with the charger is not important. Charging will commence after a few seconds. The two-color LED shows you the status:

- red: charging
- green: charging completed

⚠ WARNING If the LED is blinking, there is an error and you MUST stop charging immediately (disconnect). The cause could be a battery failure (too drained, too moist, overheated) or an issue with the connector or cables. Charging is automatic. The battery normally will reach a full charge in under 3 hours. However, charging time may vary based on battery level at the beginning of the charge. Once the battery is charged disconnect it from the charger.

CHARGING THE REMOTE CONTROL'S BATTERY

Also charge the remote control's battery with the included charger in a completely dry environment. Use the included USB charger to charge the remote control's battery. Make sure the remote control is completely dry. The charger comes with a 5V USB adapter, into which you plug the included charging cable. The charging cable's other end has a magnetic connector, which you plug into the remote control. Charging will commence after a few seconds. The remote control will light up.

- red: charging
- green: charging completed

If the LED does not light up in a few seconds, turn the magnetic connector around and connect it in the opposite position.

Charging is automatic. When the remote is fully charged, disconnect the cable.

The Drive battery and remote control batteries can be charged at the same time. It is recommended that you charge the remote control's battery after every session, just like the drive battery.

⚠ WARNINGS

- Before charging, read all instructions and warnings.
- Before charging, make sure all the components are dry, clean, and undamaged.
DO NOT charge the batteries if they appear in any way damaged!
- Only charge in a dry environment at room temperature
- DO NOT charge near flammable or volatile substances
- DO NOT cover the battery, remote control, or charger with any material while charging.
- You MUST be present during charging so you can monitor the charging process.
- DO NOT leave the battery or remote control connected to the charger after charging is complete.
- DO NOT let minors charge the batteries.
- Use ONLY the original, included cables and charger for charging the Drive and remote control.
- If something goes wrong with charging, immediately stop the process.


CONNECTING THE BATTERY TO THE DRIVE

The connector MUST be properly attached to the battery. Turn the connector around until it slides in easily (see picture 1). Lightly press the connector and turn the locking ring clockwise until it clicks. Only this way can the connector ensure a proper, watertight seal. DO NOT use any tools or other objects when (dis)connecting the connector.

It is extremely important that the battery cover is placed ONLY on perfectly clean surfaces, as any foreign object (including sand or excessive dust) can damage the watertight seal and allow water to enter the Drive. This includes the plastic around the edge where the seal on the cover rests on the drive itself. (see picture 2)

Place the drive in the board bag and head off for your first session with your board. The board bag has 2 pockets on the inside: the charger goes in one, and the fin in the other, and instructions can be kept in either one, however we recommend keeping it in the dry pocket with the charger, as the fin will likely be wet.

⚠ WARNING DO NOT take the charger with you on the water. Leave the charger safely stored in a dry place, protected from sunlight and away from any source of heat.



READYING THE SUP

Take the bag down to the water's edge. Open the bag and remove the paddle, and assemble the paddle (see step by step guide).

Unfold the SUP on a soft, flat surface. Place the Drive next to the SUP on a clean and flat surface (right on the board bag is best). Unscrew both of the screws on the Drive's cover and remove it. DO NOT be surprised if this takes a little effort (see step by step guide).

INFLATION AND INSERTION OF THE DRIVE

Connect the inflation hose to the compressor and the valve at the back of the SUP. The inflation hose MUST not be twisted or bent (see step by step guide).


Valve Operation:

The board's inflation valve is located near the back of the board. To open the valve for inflation, make sure that the center valve pin is in the "up" position. If it is in the "down" position, press down on the valve pin and turn it counterclockwise until it pops up.






To open the valve for deflation, press down on the valve pin and turn it clockwise so it locks down. Be careful of any sand or debris around the valve area when deflating as small particles could become airborne with the release of air pressure. Clean the area with a clean cloth before opening the valve, if necessary.

CAUTION! Always lock the valve cover over the valve stem when in use. This will prevent accidental air release and entrance of any particles into the air chambers. (see picture 1)


CAUTION! If the valve is in the wrong position (open, see picture 3), you will waste the battery and possibly overheat the compressor. As soon as you detach the inflation hose from the filling hole, all the air pumped in the board will immediately be released, wasting your time, energy, and not to mention nerves. Note that not following the instructions carefully may void the warranty.








STEP BY STEP PREPARATION GUIDE




Open Board valve




Make sure safety valve is closed!




12



13




14



- 1-3) unfold the bag and remove the 3 piece paddle
- 4) remove fin and inflation hose
- 5) open the board valve
- 6) make sure valve pin is in closed position
- 7) unscrew both screws and open cover
- 8) connect battery
- 9-12) attach inflation hose to drive and board correctly
- 13) assemble the paddle
- 14) attach safety & carry leash


COMPRESSOR

The compressor is activated by holding the on/off switch for 3 seconds. Activate the first inflation phase by holding the on/off button for 3 seconds. The first phase lasts about a minute and a half and will automatically shut itself off at the right pressure, but briefly pressing the on/off button will also deactivate the compressor. (see picture)



At this point place the Drive into the hole in the board (see picture), and continue with the second phase, which will take about three and a half minutes. Again the compressor will automatically stop at the right pressure. Again press and hold the on button for 3 seconds to activate the second inflation phase.

When the SUP is fully inflated after the second phase, the compressor will automatically shut off. At this point detach the inflation hose (B-side) from the valve and fasten the valve cap (see pictures &). Wait for the inflation hose to cool down, then detach the inflation hose (A-side) from the compressor(see pictures &). Wrap up the inflation hose and store it inside the board bag (see picture). Put the cover on the Drive. As with opening the cover of the Drive, this may take some force. Lean on it with your body weight (see picture). Attach it, turning the screws until they are finger-tight.



⚠WARNING Make sure the Drive is inserted in the correct direction, otherwise the motor will propel you **BACKWARD** instead of forward. Make absolute sure that the dedicated hole for the Drive is clean, with no foreign objects, sand, or dirt.

⚠WARNING The inflation hose may become **HOT** during the operation of the compressor. Handle with caution and wait for hose to cool down before touching it. **DANGER:** Not following this instruction may cause severe burns. After the inflation is completed, the hose will cool down on its own in a short period of time.

CAUTION: You **MUST** be present during inflation and monitor the process.

If for any reason you pump the board manually, use a pressure gauge to make sure the pressure is between 15 and 18 psi (1-1.2 bar).

⚠WARNING

- While the compressor is activated **DO NOT** put your hand anywhere near the underside of the Drive
- The inflation hose **MUST** not be twisted or bent.
- Inflation **MUST** be monitored in all phases, making sure to turn off the on/off switch if anything unusual or unexpected happens.

FIN ASSEMBLY

Attach the fin to your board following the instructions in the pictures. Make sure the fin is pointing in the right direction! Check the water's depth and make sure the fin is not obstructed. Check the weather and conditions.

Mounting the fin

The fin can be mounted before or after inflating the board.

1. Place the back of the fin with the pin into the mounting on the board.
2. Slide the fin backwards and push the front down.
3. Lock the fin by pushing the lever



⚠ WARNING

- The seals of the Drive and its cover **MUST** be completely clean.
- Before putting the Drive in the board's opening, make sure once again that it is facing the right direction.
- Before attaching the cover make sure that nothing is obstructing the placement of the cover. Fasten the screws manually to fingertight, without any tools or any other objects.
- There is no visible pressure gage, as inflation is automatic.

⚠ WARNING

The leash **MUST** be worn at all times! It is also used to carry the board down to the water.

Always use a life-jacket and a leash while paddling.


DO NOT carry the board in such a way that it puts pressure on the Drive.

DO NOT purposefully overturn the board while in the water; if it is overturned by accident, immediately turn it back over.

PADDLE AND REMOTE CONTROL

The paddle is collapsible and comes in 3 parts. Put the three parts together and fasten the tightening clips. Many theories exist about the optimal paddle length, so contact a local expert for more information.

Now assemble the already charged remote control as indicated in the picture. Attach it to the paddle. (see picture)



WARNING: DO NOT submerge the board remote control (which is normally attached onto the top of the paddle) more than necessary. There is no problem if the remote control gets wet or floats on top of the water, but it is not intended to be submerged under the water surface, especially at any significant depth. It is waterproof, but it is not designed to withstand the pressures of deep water. Disregarding this instruction will void the warranty.

The remote control has 4 buttons: one is an on/off switch, and 3 speeds to choose from. Slightly pressing the buttons activates and deactivates the Drive, as well as regulates the speed on the water. Tapping the on/off switch twice turns on the LED lights (if LEDs are installed).

CAUTION: DO NOT strip the thread on the screws when attaching the remote control to the paddle. Use the included tools (hex-key).

Maintaining the Remote Control

Clean the remote control after use and dry it out. If used in salt water, make sure you rinse it with fresh water afterwards. Make sure it is completely dry before charging. Also charge the battery before long periods of disuse, to avoid it draining itself. Store the remote control in a dry environment at a temperature between 50 °F/10 °C and 85 °F/30 °C degrees. Charging the remote control is recommended before every session.

For problems with the remote control, contact your dealer or customerservice@jobsports.com.

START PADDLING

NECESSARY - Start on your knees if there are any hard or sharp objects within 10 feet (3 meters). Also to ensure that the fin does not get damaged, DO NOT launch the board in water shallower than your knees.

OPERATING THE DRIVE

▲ WARNING The Drive battery, when fully charged, has a normal range of use of 3 hours at 2 knots of cruising speed, or 1 hour at top speed of 3.5 knots. Be aware that range of use may vary widely depending on operating conditions and other factors. Please note that the battery charge level indicator is ONLY intended to provide the user with a general understanding of remaining battery charge available. ALWAYS paddle within a range of distance from which you are comfortable returning using human power alone (paddling).

The Drive provides you with 3 speeds of paddle assistance.

First, turn it on by briefly pressing the on/off button. Then choose your ideal speed. You can turn the Drive off by pressing the on/off button once more. The next time you activate the Drive it will be at the same setting as when you turned it off. While the Drive is activated, a green LED will blink once per second. A red LED will start blinking when there is a problem with the RF connection. If the RF connection is interrupted for more than 1 second (falls in the water, the remote control and Drive are physically separated), the Drive will shut off automatically.

When approaching the shore again, make sure you turn off the Drive. DO NOT paddle among swimmers. DO NOT paddle into sharp rocks or other objects.

DRIVE OPERATION

PACKING UP

Take the board to a dry and clean surface. It's best that this is in the shade, as prolonged exposure to the sun increases pressure in the SUP and can lead to deformation. The Drive will also stop working when overheated. Both the Drive and board **MUST** be dry before storage.

Open the valve cap at the back of the SUP and push down the valve pin to let the air out. (see pictures 1&2)

▲ CAUTION! NEVER open the cover if it is moist! Before opening the cover make sure that no water will leak into the Drive (from your clothes or body). When the Drive is dry, open the cover. Put the dried Drive on a flat surface and unscrew the cover. Wipe off any moisture accumulated inside, and ONLY then disconnect the battery, turning the locking ring counterclockwise. Put the safety cap on the connector attached to the battery (see picture).

You can either transport the battery separately or inside the Drive.


Disassemble the paddle & fold up the SUP. (see picture)

The board in the backpack and the drive in its own bag. Transport the board in the dedicated board bag as shown in the picture. The battery can be transported in the Drive housing, as long as the battery is not connected to the Drive (connectors **MUST** be separated). Off you go!


REMOTE PAIRING

1. You need a Drive and a remote, with the Drive's battery ready and connected yet.
2. Connect battery to drive system, wait till drive loads to a stand by (red blinking light). Then you have a few seconds (app5 sec) window to simultaneous press all four buttons on the remote.
3. When pairing starts, red and green light is blinking on the remote. Pairing last circa ten seconds and if successful at the end green light lights up on remote for two seconds.
4. Now reset your Drive by disconnecting and reconnecting the main battery. The remote and Drive are now ready.

The pairing process takes about 20 seconds. If it fails, try it again. You can pair only one Drive to one remote, and they will only "know" each other. At every pairing, old pairing information is erased.




Valve pin




Open valve pin



DO NOT OPEN IF WET!



Disconnect & close battery connector



Put everything in the board bag and fold it up

BATTERY CHARGE INDICATORS

CAUTION! Clean everything EXCEPT THE INSIDE OF THE Drive. If you've been paddling in salt water make sure to rinse the board and the outside of the Drive with fresh water and dry them before transport. Clean the propeller, propeller channel, and protective mesh after every session. NEVER store the board wet. NEVER use soap to clean the board, just fresh water.

CAUTION! It is perfectly fine to use a board until the battery runs out, as it is programmed to leave a certain charge left in the battery. When left alone, however, the battery will continue to slowly discharge itself. It is your responsibility to use the battery properly according with these instructions and to monitor its state and conditions.

Charge the battery after every session, especially if you drained it during your paddling. A discharged battery can further drain itself over time past acceptable limits, damaging or even completely ruining the battery. The battery MUST also be charged before a long period of non-usage.

Dry the Drive, then clean it with a moist towel, let it sit in a dry spot for a while so that it dries out completely. The same goes for the board. The Drive MUST always be completely dry before opening its cover.

CAUTION! If the board suddenly loses speed for no apparent reason, it is likely because some plant or other object has clogged up the mesh protecting the intake to the propeller shaft. Simply turn off the Drive and reach a safe area where you can comfortably remove the objects obstructing the intake hole.

WARNING Avoid areas with visible marine vegetation or other objects floating on the water as well as waters that may be otherwise polluted. Such conditions may cause injuries to you and damage to the product. ONLY use this product in waters where you can swim safely.

BATTERY CHARGE LEVEL INDICATORS

WARNING Please note that the battery charge level indicator is ONLY intended to provide the user with a general understanding of remaining battery charge available. Users MUST ONLY use the board to cover distances that the user is comfortable reaching, and returning from, under paddle power ONLY, in the event of battery depletion or any other failure of the system.

TEST THE Drive'S BATTERY

With the Drive off, hold button 3 and click the on/off button

LED: a sequence of 4 flashes indicates the Drive's battery's charge level

- 4x green = full
- 3x green then 1x red = 75%
- 2x green then 2x red = 50%
- 1x green then 3x red = 25%
- 4x red = empty

TEST THE REMOTE CONTROL'S BATTERY

With the Drive off, hold button 2 and click the on/off button
Charge level is encoded in a combo of green and red LED,
LED:

- 4x green = full
- 3x green then 1x red = 75%
- 2x green then 2x red = 50%
- 1x green then 3x red = 25%
- 4x red = empty

CAUTION! DO NOT submerge or leave the remote control underwater for extended (unnecessary) periods of time. Water contact in normal use conditions will not cause any problems to the remote.

MAINTAINING THE Drive BATTERY AND CONNECTORS

The Drive's battery has a built-in control to protect it from harmful states during use and during charging. It is your responsibility to use the battery in good faith and monitor its state.

Charge the battery after every session, especially if you drained it during your paddling. A discharged battery can further drain itself over time past acceptable limits, damaging or even completely ruining the battery. The battery's connectors should be maintained by occasionally lightly spraying contacts with a Vaseline-based spray for connector maintenance. Also spray the connector's contacts on the Drive side. This will significantly extend the connectors' lifespan.

WARNING

- Only use the battery included or the spare battery from board. If the battery has any sign of damage or malfunction, DO NOT use it. If you need to dispose of a broken or unusable battery, consult and follow the local applicable laws and regulations regarding the disposal or recycling of Li-Ion batteries.
- DO NOT open the battery's casing.
- DO NOT replace or change the connectors yourself.
- During transport or storage NEVER let the battery be exposed to temperatures lower than freezing or higher than 115° F (50° C).
- Store the battery in a dry environment, away from any combustible or otherwise volatile substances.
- NEVER drop the battery. Always protect the battery from physical and water damage. Damage to the battery can result in overheating, melting, and fire, and it can be dangerous to your safety.

WARNING In the unlikely event that the battery catches fire, try to protect yourself and others from injury and extinguish the fire with a fire extinguisher or with sand. DO NOT try to extinguish a battery fire with water. Water is not appropriate to extinguish lithium fires.

TROUBLESHOOTING

- If no LED lights up when you attach the battery, it is either completely drained or there is a problem with the Drive. Contact your dealer or customerservice@jobesports.com.

There are 4 LEDs on the Drive:

- red, yellow, blue, and a red error LED separated from the rest

These can ONLY be seen when the Drive's cover is open, mostly as indicators of states before your session and during inflation, as well as to assist you in the event of errors or malfunctions.

When the battery is connected, LEDs show:

- the battery's state
- the status of the RF connection
- the compressor's state
- error codes

CHARGE LEVEL: is encoded in a combo of green and red LED,

- 4x green = full
- 3x green then 1x red = 75%
- 2x green then 2x red = 50%
- 1x green then 3x red = 25%
- 4x red = empty

The charge level sequence shows every 10 seconds. Meanwhile brief blinking shows the status of the RF connection

A red and green LED will shine whenever there is a connection, and the green one will blink once per second. If there is no connection, the red one will blink rapidly. During the pairing phase, when the remote control and the Drive are searching for each other, the red and yellow LEDs will blink alternately. Explanation: there is ONLY a connection when a certain function is activated on the remote control, otherwise the connection is passive.

COMPRESSOR: a blue LED will shine while the compressor is engaged. During phase 1, it will blink slowly. When the first phase is finished, the LED will blink once per second. In the second phase, it will shine continuously. At other times, the blue light does not shine.

ERROR NOTIFICATION: A red LED will indicate anytime the Drive has detected an error.

- compressor overheating: red 1x
- motor overheating: red 2x
- LED overheating: red 3x
- battery overheating: red 4x
- motor jammed/blocked: red 5x
- system error: red continuously shines

Temperature errors reset themselves when the temperature subsides. An overloaded motor is reset - after the error is addressed (such as cleaning the propeller) - by turning the Drive off and on again. System errors are corrected by unplugging and replugging in the battery.

WARNING ONLY unplug the battery when on land in a dry environment.

If the system error remains, it **MUST** be sent to be serviced.

Contact your dealer or customerservice@jobesports.com.

REPAIR KIT

All boards come with a repair kit in the event of small holes or punctures in the SUP itself. Instructions for repair are included in the kit itself. If you have a hole larger than that which can be repaired with the included kit, it shall be considered that you were improperly using the board and the warranty will not cover a repair. Depending on the size of the puncture, it might still be repairable. If you are unsure as to whether a puncture is repairable, contact Jobe and we will advise you about the appropriate steps.

REPAIRS

Propeller:

A spare propeller is included with the board. It may be replaced **ONLY** when the Drive's battery is not connected. (see picture)

Remove the protective mesh covering with the included tool, and either manually or with water clean the canal.

Hole in the SUP:

- Find the leak.
 - Deflate the SUP
 - Find or cut a suitable patch, preferably of round or oval shape.
 - Thoroughly clean the area on the SUP, with rubbing alcohol if possible. The area **MUST** be dry.
 - Put the patch on the SUP and mark on the patch size and shape needed.
 - Evenly apply sealant to the patch's outline on the SUP and on the back of the patch.
 - Wait 5 to 10 minutes for the sealant to become tacky to the touch.
 - Lightly press the patch on the area to be repaired, with the sealant sides touching.
- Make sure there are no bubbles under the patch. Press with more force and flatten it out strongly, using the back of a spoon or another hard, smooth object.
- Leave at least 24 hours to dry thoroughly


Repair kit & Repairs.

PADDLE POSITION



ADJUST YOUR PADDLE TO THE RIGHT HEIGHT

Correct height



Use clip with
lever to adjust
size

Use with logo
facing forward



3 years *Warranty*

★ ★ ★

THREE YEARS WARRANTY. REALLY.

We believe in our brand. For this reason, Jobe inflatables come with 3 years warranty. All you have to do is register your board within 2 weeks online at

jobsports.com/happycustomers